

FIG. 1




FIG. 2




FIG. 3





FIG. 4



101

141 SHIFT POSITION SENSOR

142 ACCELERATION SWITCH

143 ACCELERATION POSITION SENSOR

144 LOADING LEVER SWITCH

145 LOADING LEVER POSITION SENSOR

146 IGNITION SWITCH

ECU

115 BATTERY

131 INVERTER ASSY

121 DRIVE MOTOR

123 DRIVE UNIT

135

151 THROTTLE ACTUATOR

ENGINE

CLUTCH

GENERATOR-MOTOR

LOADING PUMP

LOADING VALVE

111

152

112

153

113

117

119

118

A




FIG. 6

